

Lab 3 – DC Motor / Propeller Characterization

Unified Engineering

27 Feb 06

Learning Objectives

- Measure thrust, torque, electrical power with prop test rig and wind tunnel
- Create motor/prop performance curves

Secondary Objectives, for Flight Competition Project

- Get familiar with propulsion terminology and propeller performance parameters

Experimental Rig

- Test Article: Propeller/motor unit in $1' \times 1'$ tunnel in Bldg 33 hangar
- Instrumentation:
 - Tunnel's pitot-static probe for airspeed measurement
 - Prop test rig with thrust and torque gauges
 - Power supply with voltage and current meters
 - Strobe for measuring RPM

Test Conditions

- Fixed motor terminal voltages: $v = 3$ Volts, 6 Volts
 - Nominal wind tunnel speeds: $V = 0 \dots V_o$ (static to zero-load condition)
- Suggested tunnel speed increments: $\Delta V \simeq 1$ m/s for $v=3$ Volts, 2 m/s for $v=6$ Volts

Wind-off Sensor Tare data, prop mounted, wind off.

- T_{tare} , Q_{tare} from load sensor. Enter these in T_{read} , Q_{read} columns for convenience.
- Take tares before and after each tunnel-speed sweep to check for drift. Use average values.
Note: Do not bump the rig during a run. This is likely to disturb the tare values.

Motor-mount Aero Tare data.

The motor mount has a small negative thrust (i.e. drag) T_0 , and a very small aerodynamic torque Q_0 , both of which must be corrected for. To reduce your test time, we provide this aero tare data in the form of aero-tare thrust area and torque volume:

$$CTA_0 \equiv \frac{T_0}{q_\infty} = -1.6 \times 10^{-3} \text{ m}^2$$
$$CQA_0 \equiv \frac{Q_0}{q_\infty} = +1.1 \times 10^{-6} \text{ m}^3$$

Raw Prop Data Acquired for each each tunnel speed sweep

- Wind-off tares T_{tare} , Q_{tare} from load cells, at beginning and end of tunnel-speed sweep.
- v from voltmeter (in Volts). Adjust power supply to hold v fixed for all tunnel speeds.
- q_∞ from tunnel's pitot-static probe in Torr. Convert to Pascals.
- T_{read} , Q_{read} from load cells.
- i from ammeter (in Amps).
- RPM using strobe. Convert to Ω (in rad/s). To avoid aliasing, start with strobe in a too-high setting, say 15000 RPM, and then reduce setting until you see the prop stop.

Data processing

- The data recording sheet can be used for hand data reduction, but a spreadsheet will be much faster and less error-prone.
- Load cell tare correction, calibration conversions, and aero-tare correction.

$$\begin{aligned} T \text{ [N]} &= 5.00 \times 10^{-3} \times (T_{\text{read}} - T_{\text{tare}}) - q_{\infty} CTA_0 \\ Q \text{ [Nm]} &= 1.47 \times 10^{-4} \times (Q_{\text{read}} - Q_{\text{tare}}) - q_{\infty} CQA_0 \end{aligned}$$

- Thrust and power coefficient calculations. These are analogous to C_L and C_D for a wing. (note extra R factor in C_P denominator!).

$$C_T = \frac{T}{\frac{1}{2}\rho(\Omega R)^2\pi R^2} \quad , \quad C_P = \frac{Q}{\frac{1}{2}\rho(\Omega R)^2\pi R^3}$$

- Advance ratio λ (analogous to α for a wing), efficiency calculations.

$$\lambda = \frac{V}{\Omega R} \quad , \quad \eta_p = \frac{TV}{Q\Omega} = \lambda \frac{C_T}{C_P} \quad , \quad \eta_m = \frac{Q\Omega}{iV} \quad , \quad \eta = \frac{TV}{iV} = \eta_p \eta_m$$

Lab Report Contents

- Name of author, and members of the lab group
- Abstract
- Sketch of experimental setup
- State the propeller being tested: APC7x4. Motor: Speed-400-7V.
- One plot of dimensional $T(V)$, two curves, one for each voltage (see Fig 2 in Lab notes).
- One plot of rotation rate $\Omega(V)$, two curves, one for each voltage (see Fig 2 in Lab notes)
- One plot of efficiency $\eta(V)$, two curves, one for each voltage (see Fig 2 in Lab notes)

Comment on how the best-efficiency speed V appears to vary with voltage.

- One plot of motor current $i(V)$, two curves, one for each voltage (see Fig 2 in Lab notes)
- Two plots of component and total efficiency $\eta_p(V)$, $\eta_m(V)$, $\eta(V)$ curves, one plot for each voltage (see Fig 7 in Lab notes). Comment on whether this prop and motor are well matched.
- Determine V_o and aerodynamic pitch P_{aero} for each voltage. Compare your P_{aero} values with manufacturer's stated pitch P
- Three dimensionless coefficient plots. Two curves on each plot, one for each voltage:
 - $C_T(\lambda)$
 - $C_P(\lambda)$
 - $\eta_p(\lambda)$

Comment on the usefulness of these curves for determining the propeller's dimensional thrust and torque for any V , Ω combination.

- Estimates of uncertainty and errors in results.

